Photoelectric DC thru beam sensors

Product Data						
Electrical Data						
	Transmitter	Receiver				
Supply Voltage	10-3	32 V dc				
Voltage ripple	+/- 15%					
Reverse polarity protected	Yes					
Short circuit protected	-	Yes				
Current consumption	25 mA / 10 V dc, 10 mA / 32 Vdc	8 mA / 10 V dc, 10 mA / 32 V dc				
Max. output load	-	100 mA				

Environmental Data Temperature, operation

Sealing class Approvals

.

Available Models						
	Model	Output	Output Mode	Sensing Range		
Transmitter	SMT 6000			1-6 m, adjustable		
	SMT 6001	-	-	6 m		
Receiver	SMR 6002	NPN	Light operated (N.C.)			
	SMR 6102	NPN	Dark operated (N.O.)			
	SMR 6202	PNP	Light operated (N.C.)	2 m		
	SMR 6302	PNP	Dark operated (N.O.)			
	SMR 6402	NPN/PNP	Dark operated (N.O.)			
	SMR 6502	NPN/PNP	Light operated (N.C.)			
	SMR 6006	NPN	Light operated (N.C.)			
	SMR 6106	NPN	Dark operated (N.O.)			
	SMR 6206	PNP	Light operated (N.C.)	6 m		
	SMR 6306	PNP	Dark operated (N.O.)	0 111		
	SMR 6406	NPN/PNP	Dark operated (N.O.)			
	SMR 6506	NPN/PNP	Light operated (N.C.)			

Connection

Wiring Diagrams Transmitters

Brown 1 Black 4 Black 4 Blue 3 Blue 3 Blue 3

Black 4 Blue 3

Receivers

-20 to +60 °C

IP 67

SMT 6000 Variable range and test input

Black 4 Black 4 Blue 3 Blue 3



SMR 600X / SMR 610X

SMR 620X / SMR 630X Transistor PNP

Transistor NPN

SMT 6001 Test input



SMR 640X / SMR 650X Transistor NPN/PNP – load as NPN



SMR 640X / SMR 650X Transistor NPN/PNP – load as PNP Connection Wires/Pins Cable 3 pin, M8 plug 4 pin, M8 plug 4 pin, M12 plug Supply + Brown Pin 1 Pin 1 Pin 1 Supply -Blue Pin 3 Pin 3 Pin 3 Control/Output Black Pin 4 Pin 4 Pin 4 Output White Pin 2 Pin 2 4. .2 Sensor plug Sensor plug Sensor plug

Mounting & Alignment

Mounting & Alignment

- 1 Mount the transmitter and receiver sensors facing each other. Make sure the distance between the sensors does not exceed the specified sensing range of the system.
- Align the sensors by moving, either the transmitter or receiver sensor, horizontally and vertically until the output is: - Deactivated when no object is present. (Dark operated)
 - Activated when no object is present. (Light operated)
- 3 Fasten the transmitter and receiver sensors securely.
- Avoid acute angles on cable close to sensor.

Adjustments

Output Logic						
Detection	Output Mode	Output status	Yellow LED			
Object absent □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□	Dark operated (N.O.)	Open	Off			
Transmitter Receiver	Light operated (N.C.)	Closed	On			
Object present	Light operated (N.C.)	Open	Off			
Transmitter Receiver	Dark operated (N.O.)	Closed	On			

Transmitter Power Adjustment

Maximum transmitting power can be used for most applications. Maximum transmitter power (factory set) is advised for applications with contaminated environments.

The transmitting power can be adjusted externally via the wires of the transmitter sensor. Adjust using a resistor (e.g. potentiometer) of 2 - 20K ohm or a voltage source of 1 - 4 V dc connected respectively between control and – (negative) supply wires. Adjustment of transmitter power may be required in applications where objects to be detected are small or translucent. Proceed with the following steps:

- 1 Select target object with the smallest dimensions and most translucent surface.
- Place target object between transmitter and receiver sensors. If the output status changes, adjustment is not required. If the output status has not changed proceed to step 3.
- Decrease the transmitter power (by reducing the resistance) until the output status changes. If the output status has not changed, attempt to move the sensors further apart or angle one of the sensors, and then repeat procedure.
- 4 Remove target object. Observe the output status has changed.
- Note: If the transmitter power adjustment is not to be used, it is recommended to connect the control wire to + (positive) supply wire.

Test Input

The transmitter can be externally disabled and enabled, via the control wire, for test purposes. The test input requires the control wire to be connected to – (negative) supply wire. Make sure no object is present in the detection area when transmitter is disabled for test. When the transmitter is disabled, the receiver should change output.

Enable transmitter Open (off) control switch, a resistor over 2 Kohm or voltage over 4 V dc

Disable transmitter Close (on) control switch, a resistor below 2 Kohm or voltage below 0.7 Vdc Note: If the test input is not to be used, it is recommended to connect the control wire to + (positive) supply wire.



Warning

This device is not to be used for Personnel Protection in Machine Guarding Safety applications. This device does not include the selfchecking redundant circuitry necessary to allow its use in personnel machine guarding stand-alone safety applications.



SMT 6000